

AV610 CaptionPort™



EEG Enterprises, Inc.

586 Main Street

Farmingdale, New York 11735

TEL: (516) 293-7472

FAX: (516) 293-7417

Copyright © EEG Enterprises, Inc. 2018

All rights reserved.

[This page left intentionally blank]

Table of Contents

- Introduction..... 2**
 - Product Description..... 2
 - List of Features 2
- Unit Setup..... 3**
 - Quick Network Setup 3
 - Video Input/Output..... 3
 - Test Captions..... 3
 - Setting Audio Levels 4
 - Accessing the Web Interface..... 5
 - Setting Date & Time 5
 - Updating Your CaptionPort 5
 - Video Output Scaling and Caption Placement Settings 6
- Lexi Setup and Testing 7**
- iCap Setup and Testing..... 10**
 - Monitor / View Captioner History with iCap Admin Logs..... 13
- Other Live Captioning Methods 14**
 - Modem (Optional Add-on)..... 14
 - Telnet 14
 - RS-232 / RS-422..... 14
- Hardware Reference 15**
 - Front Panel..... 15
 - Rear Panel 16
 - RS-232 / RS-422 Connection Detail 17
 - AV610 CaptionPort Specs..... 19
- Developer Features..... 20**
 - Command Concept..... 20
 - Startup Settings..... 21
 - Command Reference..... 22

Copyright 2018, EEG Enterprises, Inc. All rights reserved. The contents of this manual may not be transmitted or reproduced in any form without the written permission of EEG.

The revision date for this manual is **June 20, 2018**.



Introduction

Product Description

The AV610 CaptionPort delivers world class caption connectivity designed specifically for video conference displays, with easy setup and cost efficiency in mind. In addition to displaying captions, the CaptionPort keeps presentations fully visible by scaling the input video down by 15% with the option of placing caption data above or below the video area. This feature allows the use of standard presentation templates without visual interference from captions. The AV610 lets you source captions from thousands of live captioners over our iCap network or automatically from our automatic captioning service, Lexi. Connectivity and testing instructions for both services are provided in this manual.

List of Features

- ✓ **Connectivity to Lexi, EEG's Cloud-hosted Automatic Captioning service.**
- ✓ **Connectivity to iCap, EEG's global network of caption service providers.**
- ✓ **Video Output Scaling feature: Scales video down by 15% and allows placement of captions above or below the presentation area.**
- ✓ Local **logging of caption input** for future reference
- ✓ Relay-bypassed master video path



Unit Setup

Quick Network Setup

To use iCap or Lexi and to access further features on the CaptionPort's web interface, you must first select **Network Settings** from the front panel LCD menu and setup the unit on your network.

- ✓ **Use a Static IP address on your network to assign the CaptionPort (recommended).** It doesn't have to be, and in most cases should not be, a publically routable IP address.
- ✓ **Program a gateway address** – the gateway address is typically the local network address of your router. This is necessary if you plan to connect out of your local network to iCap or any other application from the CaptionPort.
- ✓ **Program a Subnet Mask** for your network
- ✓ **Lexi only: Program your network to allow outbound connections to <https://eegcloud.tv> on port 443.** Your device must also have a valid DNS server configured under the Network tab on the web portal. See additional Lexi setup instructions on Page 6.

As an alternative to these recommended steps you may also set up the device for DHCP – Selecting DHCP will automatically pull available IP, gateway, and subnet information from your network.

IMPORTANT: With DHCP, your device's assigned IP may change on its own which will affect how you access the web interface for your device.

Video Input/Output

Put SDI video into the unit. Output captions will appear on the SDI video output. Refer to page 19 for a diagram of the rear-panel connector.

Test Captions

With video input connected to the CaptionPort, you can send a stream of auto-generated test captions to the output video to ensure proper initial setup of the device. To send test captions navigate to **Utilities > Test Captions > Enable > On** and a stream of test caption text should appear on the output of your CaptionPort. Note that video input is required to send test captions.

Setting Audio Levels

Your program audio source is typically embedded in the standard video input to your CaptionPort. Audio may also originate from a separate Analog or AES source (XLR connector input to unit). To send this program audio to captioners through iCap, you must first configure the audio settings through the front panel menu of the unit.

From the main menu go to **Audio Setup > Audio Mix** and set to *Stereo* or *Surround* appropriately. Next, visit **Audio Setup > Peak Level** and ensure the audio level peaks at around 80% and does not warn “Clipping!” This step is crucial for ensuring that quality audio is being sent to the captioner (quality audio = quality captions).

If your audio levels are too low, or too high – you can achieve an appropriate level by adjusting the audio source itself or simply adjusting the source audio level from the CaptionPort front panel LCD menu **Audio Setup > Scale Audio** which allows you to scale the audio up or down in 6 decibel increments.

Detailed Explanation of All Audio Setup Menu Options

Input Select	Selects whether the input audio format is analog, AES digital or embedded audio. Use the LEFT and RIGHT keys to select the correct format, then press ENTER to exit and apply changes or CANCEL to exit and cancel changes. The CaptionPort does not currently support direct input of Dolby® E or other compressed audio signals.
Peak Level	Dynamically displays the peak signal level at the audio input. A warning message will be displayed when clipping is detected at the input. For optimal sound quality, the peak level bar should reach at least 60% across the screen, but should never display “Clipping!”
Scale Audio	Adjusts the audio input level without adjusting the output level of your source. The built-in digital input trim can boost or cut the audio input level up by as much as 12 dB.
Audio Group	Selects the SDI embedded audio channel group that the iCap™ mix is sourced from. Up to 4 channel groups can be carried on an SDI signal, though most commonly Group 1 carries the primary audio program. <i>Applies only when embedded audio input is selected.</i>
Audio Mix	Selects whether the iCap™ mix is being created from a Stereo or Surround channel group. Choose “Stereo” to select a mix of the left and right channels (1 & 2 or 3 & 4 within the selected Audio Group, according to the Stereo Channel setting), or “Surround” to select a mix of the left, right, and center channels (1, 2 & 3 within the selected Audio Group). <i>Applies only when embedded audio input is selected.</i>
Stereo Channel	Selects whether the iCap™ stereo mix is being created from channels 1 & 2 or channels 3 & 4 within the selected Audio Group. <i>Applies only when embedded audio input AND stereo audio mix are selected.</i>

Accessing the Web Interface

The web interface of your device can be accessed through any computer on your local network and controls many of the CaptionPort's applications, configurations, and features. You will see it referenced many times throughout this manual.

The device must be connected on your network to access the web interface (reference *Quick Network Setup* section on page 3). The web interface is accessed by entering the IP address assigned to your device in your computer's web browser. If you set the device up with a static IP address, the address for your web interface will be the same. If you set the device up with DHCP, the address can change at will and you should check the IP from the front panel of your CaptionPort at **System Setup > Network > IP Address** to ensure you are using the correct IP to access the web interface.

Setting Date & Time

The Date and Time can be set by selecting Date/Time from the side menu on the web interface.




Figure 1: Date/Time Settings on the Web Interface

Updating Your CaptionPort

Before updating you must first download the latest update file for your device model from the product updates section of our website https://eegent.com/support/product_updates

Once you have downloaded the latest version you can apply it to the CaptionPort either through the web interface OR the front panel USB port / LCD Menu.

- ✓ **Web Interface:** Select *Update* from the left side menu. Browse for the update file downloaded from our website, then click *Upload*, and finally click *Proceed*.
- ✓ **USB / LCD:** Transfer the update file to any USB stick. Insert the memory stick into the front panel USB port, navigate to the **System Setup > Update** from the LCD menu, and press enter to proceed and install the update. A message will appear on the LCD screen when the update has finished. **Do not remove the memory device while the update is running.** Some updates will require a power-cycle before they take effect; in this case, the unit will power down automatically once the update is complete.

Video Output Scaling and Caption Placement Settings

A distinct feature of the AV610 CaptionPort that sets it apart from other captioning units is the video scaler feature. By scaling the input video down by 15% you have the option of placing caption data above or below the video area. This feature allows the use of standard presentation templates without visual interference from captions.

From the main **General System Information & Status** page of the web interface look for the **Video Output Scaling** feature. Select the option from the dropdown that you would like represented on the captioned video output of your CaptionPort.




Figure 2: Video Output Scaling Options on the Web Interface



Figure 3: Example of Scaled Video Output with Captions Above Viewing Area



Lexi Setup and Testing

If you did not indicate interest in Lexi at the purchase of your CaptionPort, please contact EEG technical support at 516-293-7472 option 4 at the menu to obtain the necessary iCap and Lexi / EEG Cloud credentials. Also, be sure your AV610 is properly setup on your network prior to setting up Lexi (instructions on Page 3).

Please note that an iCap account is required for your CaptionPort to communicate with Lexi over a standard broadband connection.

1. Confirm iCap Connectivity and Know Your iCap Access Code:

- ✓ **From the main page of web interface, confirm the iCap Status says *Connected to remote server*. Additionally, the iCap LED on the front panel of your CaptionPort should be green.** If inactive, contact EEG support for credentials.
- ✓ **Your iCap Access Code can be found in the shipping documentation provided with your Device.** This will be used in the next step to enable Lexi to access live program audio from, and return automatic captions to, your CaptionPort over iCap.

The screenshot shows the 'General System Information & Status' page of the web interface. The 'iCap Status' is highlighted with a green box and shows 'Connected to remote server (Active)'. Other system information includes:

System Information	Value
Local Time	Thu May 17 18:09:47 EDT 2018
System Uptime	0 hour, 31 minutes, 39 seconds
System Load	CPU: 9.6% Disk: 0.6/26.1 GB (3%)
System Information	EEG EN537, Unit ID: 9876, Build 2.0.0, Firmware v1.52
Network Configuration	IP: 100.200.200.135 Subnet Mask: 255.255.255.0 Gateway: 100.200.200.1
iCap Status	Connected to remote server (Active)
Current Program	Name: Unknown (Rating: Unknown)
Modem Status	A: MA Not installed B: MB Not installed
Active Ports	S1: Regenerating upstream captions S2: Regenerating upstream captions [Force Regen]
Video Inputs	Main: 1080i60 Aux: none
Test Captions	Test captions: Not running [Switch Test captions On]
GPI Settings	GPI-A: Force 608 Up-conversion

Figure 4: Active iCap Status on Web Interface Main Page

2. Configure Lexi from the Web Interface

- ✓ **Select the Lexi module from the left hand menu of the web interface. Enter your EEG Cloud Username and Password along with your iCap Access Code.** If this information has not been preconfigured prior to shipment, noted in the paperwork that came with your CaptionPort unit, or provided to you via e-mail by EEG Support contact us at 516-293-7472 option 4 to setup your Lexi account and obtain this information.
- ✓ **Ensure additional preferences are configured as desired.** Below are descriptions for each setting field. Once this is complete you may **click Apply Settings**.

The screenshot shows the 'Lexi™ Automatic Captioning' web interface. It is divided into several sections:

- Login:** Fields for EEG Cloud Username (support@eegent.com), EEG Cloud Password (masked with dots), and Access Code (eegtest).
- Lexi Status:** A table showing Status as 'No job running' and Version as '1.1.2'.
- Speech Recognition:** Fields for Language (English-US) and Custom Model (Headline News (USA)).
- Caption Display:** Fields for Caption Service (CC1/S1), Number of Rows (3), Vertical Position (15 (bottom)), Horizontal Position (0 (left)), and Force Capital Letters (Disable).
- Lexi Client:** Fields for Enable Module (Disable), Activation Mode (Always active), Inactivity Timeout (10 minutes), Block Lexi on Upstream Captions (Yes (5 seconds)), and Monitor Service with GPO 2 (checkbox).

An 'Apply Settings' button is located at the bottom right of the configuration area.

Figure 5: Lexi Module on the Web Interface

Speech Recognition

Language The base language models supported by Lexi currently include English-US, English-UK, and Spanish.

Custom Model Through the EEG Cloud web site, you can manage your Lexi account and create custom language models to further improve accuracy for your unique application. This dropdown box will display all of the custom models available under your active EEG Cloud account.

Caption Display

Caption Service	Choose from primary language (CC1/S1) and secondary language (CC3/S2) options.
Number of Rows	The number of rows per roll-up caption can range from 2 to 4.
Vertical Position	CTA-608 base row options range from 2 (top of the screen) to 15 (bottom of the screen).
Horizontal Position	Choose a left horizontal offset from 0 to 28 characters.
Capital Letters	When enabled, all captions will be written in upper-case.

Lexi Client

Enable Module	Lexi must be enabled in order for the CaptionPort to communicate with Lexi and receive captions from the cloud.
Activation Mode	When "Always active" is selected, a Lexi captioning job will be started immediately upon enabling the client module.
Inactivity Timeout	A Lexi job that that runs for this amount of time without any dialog being transcribed will be terminated automatically by the server. Set to "None" if you want jobs to be able to run indefinitely without dialog.
Block Lexi on Upstream Captions	Setting this to "Yes" will ensure that Lexi will not generate captions when upstream data is present. The time in parentheses indicates how long upstream captions will have to be absent in order for Lexi to start up again.
Monitor Service With GPO 2	When selected, GPO 2 will be active when Lexi is captioning to the selected access code, and will be inactive otherwise.



iCap Setup and Testing

This section will walk you through a basic test of iCap and point out important information your captioner will need from you to get started. For sections that require you to access the iCap admin site – iCap Admin credentials are supplied by EEG at the time of unit purchase/rental along with your unique access code and is accessed at <https://www.eegicap.com/iCapAdmin>. If you did not indicate iCap usage at the purchase of your CaptionPort, contact technical support at 516-293-7472 to be set up with iCap.

1. Connect iCap From the CaptionPort Web Interface:

- ✓ Select *iCap* from the menu on the left and confirm that the *Company Name, User Name, and Password* are all present and correct.
- ✓ On the same page confirm that iCap Status says *Connected*. Additionally, the **iCap LED on the front panel of your CaptionPort should be green**. This also means the CaptionPort is connected to iCap.
- ✓ If all information is correct and the status does NOT say *Connected* – try clicking the *Start* button found on this page to connect to the iCap Network. *An iCap Connectivity indicator light on the left face of the CaptionPort will also show green when iCap is connected and red if not connected.*

The screenshot displays the 'iCap Web-based Configuration' interface. It is divided into several sections:

- Login:** Fields for Company Name (EEGTV), User Name (pk492), and Password (masked with ***).
- Server Name:** Field for Remote Server (eegicap.com).
- GPO Monitoring:** Checkboxes for 'Monitor connection on GPO 3' and 'Monitor S1 activity on GPO 4', both checked.
- Audio:** Checkbox for 'Use high bandwidth audio', checked.
- Video:** Checkbox for 'Send video frames (iCap Broadcast Plus accounts)', checked.
- iCap Status:** A table showing:

Status	Connected
Server Type	Main
ComCC Status	Off
Audio Packets Sent	0
Relay ID	643641629
Version	3.3.1
iCap Running	Yes
- iCap Client:** 'Start' and 'Stop' buttons.
- Misc.:** 'View iCap Admin' link.
- Footer:** A green success message 'Success! Settings saved!' and 'Apply' and 'Reset Connection' buttons.

Figure 6: iCap Module Settings on the Web Interface

2. Know Your iCap Access Code:

- ✓ Your **Access Code** is what you provide to your captioner so that they can Access your program audio and provide live captions through iCap.
- ✓ Your unique **Access Code can be found in the shipping documentation** provided with your CaptionPort. It may also be found by logging into the iCap Admin website at eegicap.com/iCapAdmin (login credentials provided by EEG Support).
- ✓ ONLY “share” your Access Code with your caption service provider in the iCap Admin site. *Your access code may already be shared with them in iCap Admin if you provided the information to EEG as part of your order. This can be verified in iCap Admin.*

3. Coordinate Testing With Your Caption Service Provider

****This step requires your caption provider to connect to your CaptionPort from their iCap software. You MUST connect your audio/video input to the unit BEFOREHAND.***

- ✓ Once you’ve provided your access code to the captioner and connected your program video/audio to the CaptionPort you will test your connection to ensure audio is reaching them and caption data is coming into your device.
- ✓ **Enter the iCap Admin portal.** In the Users tab - confirm audio status for your CaptionPort says “Audio OK” (see figure 7) - this means your captioner is receiving Audio. If the Status says “No Listeners” it means that the captioner has not yet connected to your access code and you should verify that they have done so. The Users tab shows all users connected to your device and confirms their status.

iCap Users for company EEGTV						
Name	Type	Online	Access Code	CC Activity	Status	
bills492	encoder	Yes			Audio OK	
bills490	encoder	Yes			Audio OK	

Figure 7: iCap Admin Users Tab with Audio Status

(Cont. on next page)

- ✓ Once you've confirmed the audio - click on the *Access Codes* tab to confirm incoming CC Activity from your captioner. Once the captioner presses "Start" on their iCap software the CC Activity in iCap Admin should read "Active" (see figure 8). Alternatively, confirm the **CC LED on the front panel of your CaptionPort is green**. This means that your CaptionPort is receiving caption data from your captioner.

Name	Service	Primary Encoder	Secondary Encoders	Listeners	CC Activity
bills492	1	EEGTV bills492		1	Active
bills490	1	EEGTV bills490		0	

Figure 8: iCap Admin Access Codes Tab with CC Status

- ✓ iCap Audio and Caption activity can also be verified locally by taking the following additional measures in the web interface.
 - Check the *Audio Packets Sent* under the iCap menu in the web interface. If the number is growing then Audio is being sent to the captioner. If it says 0, check with your captioner to ensure they have connected.
 - Check caption activity by selecting *Logs* from the side menu on the web interface. Then look for iCap, and select the log with today's date. The iCap log will show some communication data which means that captions are being received.

Alternatively, you can view the "Clone" logs section which will show all binary commands received - also indicating captions are coming through the connection.

Monitor / View Captioner History with iCap Admin Logs

To monitor or view past captioner connection history to your CaptionPort’s access code, login to iCap Admin and select the *Logs* tab. Next, select either the access code you want to see history for. Once you’ve selected the desired access code, an event log will appear that you can view to see all activity on your access code.




Figure 9: iCap Admin Logs Tab



Other Live Captioning Methods

Modem (Optional Add-on)

Standard RJ-11 connection. Connect to a phone line to enable dial-up captioning and provide your captioner with the telephone number associated. Using a PBX or other digital non-POTS system is NOT recommended - many of these are not compatible with modem communications. Once connected, the LED on the front panel of your unit labeled “MDM” will turn green.

Telnet

Enable telnet via the web interface and select a port. Configure your firewall to allow a captioner to get to your CaptionPort on the designated port and then give your caption service provider the port number and public IP address.

RS-232 / RS-422

See hardware section for cabling detail. Serial port settings are controlled through the web interface selecting **Serial Ports** from the left side menu or by navigating to **System Setup > P1 Mode** from the front panel LCD menu. The CaptionPort supports RS-232, RS-422, and RS-422 Sony (with RS-422 and RS-422 Sony options configurable on Port 1 only). Default settings are 1200 baud, odd parity, and 7 data bits. Customized settings are sticky after power cycles. Modem will automatically take priority when active so that the prompter can be overridden as desired.





Figure 10: Serial Port Settings in the Web Interface



Hardware Reference

Front Panel




Power Switch	There is one power switch on the rear panel for each power cable connected to the unit.
Power On LED	There is one power LED for each power supply connection provided with the unit
Active	Toggles the CaptionPort between active operations and Relay Bypass mode. In Relay Bypass mode, the signal at the master video input is routed directly through to the master video output, while the signal at the auxiliary video input is routed directly through to the auxiliary video output. Video output 2 is inactive.
Active On LED	The Active On LED will light green when the unit is in active operating mode. The LED will turn off when the CaptionPort is in Relay Bypass mode.
LCD Screen	The LCD Screen provides access to the unit's front panel configuration menu. Status information is displayed when the menu is not in use. Press the "check mark" button to enter the menu at any time.
Control Pad	The Control Pad provides menu navigation for the front panel configuration menus. The control pad buttons are: ENTER (marked by a check), CANCEL (marked by an 'X'), LEFT , RIGHT , UP , and DOWN .

USB Port

The front panel USB port provides firmware upgrade capability via a flash memory device. Updates can be applied through the USB port as well as the web interface. See *Updating Your CaptionPort* section on page 5 to learn more.

Rear Panel



Primary Power 1

AC power input, 120 – 240 V, 50-60 Hz tolerant. Connects to the unit’s AC power source. Corresponding switch powers unit on or off.

Optional Power 2

AC power input, 120 – 240 V, 50-60 Hz tolerant. Connects to the unit’s AC power source (second power supply does not come standard).

GPI In & Out

Two blocks of 8 GPI input switches and 8 GPO output notifications. Switch functions vary based on software configurations.

Ethernet Port

Used to connect the CaptionPort to your local network for access to the web interface and Lexi. The CaptionPort will be reachable on your network using the static or DHCP IP address set in the front panel configuration menu.

Master Video In

Input for program video source - can use 3G-SDI, HD-SDI, or SD-SDI

Out 1

Relay-bypass protected primary video output.

Out 2

Non relay-bypass protected copy of the primary video output signal.

RS-232 / RS-422 Connection Detail


Both Serial ports 1 and 2 use DB-9 connectors. Only serial port 1 supports RS-422 and RS-422 Sony. See the following PIN assignments:

RS-232 Protocol		
Pin	Master	AV610
1		
2	Rx	Tx
3	Tx	Rx
4		
5	Ground	Ground
6-9		

RS-422		
Pin	Master	AV610
1	Rx-	Tx-
2	Rx+	Tx+
3	Tx+	Rx+
4	Tx-	Rx-
5	Ground	Ground
6-9		

RS-422 Sony		
Pin	Master	AV610
1		
2	Rx-	Tx-
3	Tx+	Rx+
4		
5	Ground	Ground
6		
7	Rx+	Tx+
8	Tx-	Rx-
9		

DB-9 Female connector pinout on rear of the unit:



These ports can be connected directly to a standard PC serial port with a 9-pin, three wire straight serial cable. A “null modem” cable MAY NOT be used for this purpose since it will reverse the connections of pins 2 and 3. Null Modem cable may be used only when the intent is to connect two units together via the serial port (see *Cloning* on page 17).

AV610 CaptionPort Specs

HD-SDI Video Inputs

Number of Inputs	2
Connector	BNC per IEC 169-8
Format	3G (SMPTE 424M), HD (SMPTE 292M), and SD (SMPTE 259M and 344M)
Input Level	800 mV p-p \pm 10%
Input Impedance	75 Ohms
Equalization	Automatic up to 100m @ 3 Gb/s with Belden 1694 or equivalent

HD-SDI Video Outputs

Number of Outputs	3
Output 1	Master (relay bypass protected)
Output 2	Master copy
Decoder Out	Auxiliary (relay bypass protected)
Connector	BNC per IEC 169-8
Output Level	800 mV p-p \pm 10%
Output Impedance	75 Ohms
DC Offset	0V \pm 0.5V
Rise/Fall Time	200 pS nominal
Overshoot	< 10% of amplitude
Wide Band Jitter	< 0.2 UI

DATA PORTS

LAN	RJ45 connector, 10/100/1000 Base T TCP/IP
USB	Three standard USB ports, one on front panel and two on rear
Serial Ports	Two serial DB-9 jacks, Selectable RS-232C / RS-422.
Serial Data Input Format	7 data bits, odd parity, 1 stop bit, settable between 1200-38400 baud
Modem	Paid Option. One RJ-11 telephone jacks 1200/2400 baud
GPI/GPO	Two ports which each mate to female IDC-16 connectors, Switches rated to 1A / 30 VDC

AUDIO PORTS

Port 1	LTC time code input
Port 2	Program audio input for streaming audio applications
Connector	Female XLR
Format	Balanced analog or AES balanced 110-ohm digital

FRONT PANEL

Display	Back-lit LCD display with six-button keypad and navigable menus for unit configuration
Power	Unit power switch with LED indicator
Active On	Unit bypass switch with LED indicator

PHYSICAL

Dimensions	19" rack mount x 1 RU x 16.5" deep
------------------	------------------------------------

ELECTRICAL

Power Supply	115/230V AC 50/60Hz
Power Consumption	Inrush: 118VA 36W Normal: 40VA 36W .31 Amps .91 Power Factor



Developer Features

Command Concept

Commands allow you to communicate with and control the operation of your CaptionPort either manually or through your custom written software that contains any combination of the commands detailed in this section. All commands begin with a leading control code of <CTRL+A> or the ASCII hex code 01 for developers writing software. All commands must end with a carriage return (the <ENTER> key on a keyboard or 0D in ASCII hex). For manual entry of commands, the three following methods may be used. A Full Command Reference may be found at the end of this section.

Telnet: Commands may be entered through a telnet connection to the device only after you've enabled a telnet connection through the web interface (select Telnet from the side menu)

Web Terminal: The Command Terminal is found on the web interface (select *Terminal* from the side menu). This emulates the serial port interface to the device and allows you to enter commands directly from the web interface (see figure 19).

RS-232: Commands may be entered through an RS-232 connection to the unit. Default settings allow entry through RS-232 right out of the box.





Figure 14: Command Terminal on the CaptionPort Web Interface

Startup Settings

The Startup Settings Editor enables entry of commands that will run every time the CaptionPort starts up. Use Startup Settings whenever you want a setting to be “sticky”; settings entered through the Web Terminal or the serial port only are not sticky and will revert to defaults when the CaptionPort is power-cycled. Startup Settings can be accessed via the web interface by selecting *Startup Settings* from the side menu.

To use the Startup Settings editor, type any desired command from the Command Reference on the next page into the command box. *Omit the <CTRL+A> character entirely as this character is implied at the beginning of each line.* To add additional commands, press the ‘+’ button and more lines will appear.

When you have entered commands for all the settings that you want to make sticky, click Update Startup Settings. The configuration changes will take the next time the CaptionPort starts up.



The screenshot shows a web interface titled "Startup Settings Editor". It features a table with two columns: "Command" and "Meaning". Below the table is a text input field. At the bottom of the interface, there are two buttons: "+ Add Command" and "Save".

Command	Meaning
<input type="text"/>	

+ Add Command Save

Figure 15: Startup Settings on the Web Interface

Command Reference

Local Entry Modes

Regeneration Mode:

Regenerate Upstream VANC	<CTRL+A>! [ON/OFF] <ENTER>
Ignore Upstream Caption Channel	<CTRL+A>6 Channel <ENTER>
Return Upstream Caption Channel	<CTRL+A>7 Channel <ENTER>
Begin PassThru Mode	<CTRL+A>3 [Pairing] [Field] <ENTER>
End PassThru Mode	<CTRL+C>
Begin RealTime Mode	<CTRL+A>2 [Channel] [Rollup] [bBase] <ENTER>
End RealTime Mode	<CTRL+C>

Status Commands

Status Commands:

Report Identification	<CTRL+A>? <ENTER>
Report Port Activity	<CTRL+A>O <ENTER>
Modem Status	<CTRL+A>+ [Modem] <ENTER>
Recovery Status	<CTRL+A>A <ENTER>
SD Video Presence	<CTRL+A>b <ENTER>
Monitor Line 21	<CTRL+A>5 [Channel] [I/O] <ENTER>
End Monitoring	<CTRL+C>